

EKO TOUCH sensor

M2 standard

Cod: KE818B013

Technical features

- Suitable for armchairs and sofas with electric mechanisms
- Touch sensitive
- To be used only with EKO control box (KE888B0010)
- Buttons installation options: Nut with satin button Ø15mm
Crimping with chromed button Ø15mm
- High noise immunity (electrostatic discharge, environmental noise, etc ...)
- Cable length : junction to unit connector : 95 cm
junction to buttons : 40 cm
- Fully customizable assembly inside the sofa due to the new sensor's position near the buttons.



Chrome



Satin

Functions

- Button 1 opens actuator n°1.
- Button 2 closes actuator n°1.
- Button 3 opens actuator n°2.
- Button 4 closes actuator n°2.



Installation

In order to install the system please refer to the installation manual.